



Vorhang-Schiene Sileno




Wand-Montage








B Variante



Spanner




Verbinder



Montageanleitung



GB mounting instruction | NL montage instructies | PL montaż instrukcje
TR montaj talimatlar | RU сборка инструкции
IT montaggio istruzione | FR Assemblée directives | RO asamblare instrucțiuni
SK montáža navodil | CZ montáž instrukce | HU gyűlés utasítás

Vorhang-Schiene
Sileno






Vorhang-Schiene Sileno



Decken-Montage




Wandabstand: $x1 = x2 = x3$



Wand-Montage



Wandabstand min. | max.:
52 - 105 mm



A Variante

