







A + B





C + D








A + B + C + D



A + B + C + D










A + B





Montageanleitung Vorhang-Schiene


- (GB) Mounting instruction
- (NL) montage instructies
- (PL) montaż instrukcje
- (TR) montaj talimatlar
- (RU) сборка инструкции
- (IT) montaggio istruzioni
- (FR) Assemblée directives
- (RO) asamblare instrucțiuni
- (SK) montáža navodila
- (CZ) montáž instrukce
- (HU) gyűlés utasítás




- A**  **1-Lauf**
-  **2-Lauf**
-  **3-Lauf**
- B**  **+ Sichtblende**
- C**  **+ Rundbogen**
- D**  **+ Rundbogen + Sichtblende**




1-Lauf




2-Lauf




3-Lauf







B + D




C





D




A



B



C



D

